

## VILLAGE DEPOT



S SCALE

### Gas Powered ROAD ROLLER

**Assembly:** We recommend ACC glues for assembly. Clean all parts of flash, then smooth with 0000 steel wool. Use the .020 wire for the steering wheel and front roller axle. Use the 1/32 wire for rear axle. Stick chain to front yoke and run under roller to an imaginary point. Paint and weather, and your ready to roll. Might also add some cans, buckets or a wheelbarrow to the scene, also available from the Village Depot.

Thank you for your purchase of our product. We hope you enjoy it, and watch for our ads in your favorite Railroad Magazine. *Thanks*

